

main burner will turn off since the sensor is designed to stop cooking when the rice pot exceeds the temperature of boiling water. Override the sensor to continue cooking by pushing down the button labeled "COOK". Verify burner ignition. The rice pot will now serve as a brazier and will not shut off automatically until the sensor is reset as described below. Allow oil to heat to frying temperature. Add one or two grains of rice to test. When grains of rice are frying add the balance of the rice. Stir the rice constantly in the oil for 7-10 minutes. Rice will burn if not constantly stirred. When rice starts to turn yellow add garlic. Stir for one minute. Stir in crushed tomatoes and allow to fry for another minute. Add and stir in cooled chicken stock, chicken, cilantro, jalapeños, lemon juice and salt. Stir thoroughly to mix and ensure no food has stuck to the bottom of the pot as that could cause the unit to shut off too soon. Cover the rice pot. You should hear a "click" indicating that the sensor has reset. Rice cooker sensor will automatically turn off the main burner when the rice is cooked.



Electronic

56822 25 Cups, 120v

56824 25 Cups, 230v

57137 37 Cups, 120v

57138 37 Cups, 230v

57155 55 Cups, 230v

View

PDF

Electronic controls and sensors replace manual switches. Customers report better rice quality and more dependable performance.

Features

- Electronic Cook and Hold
- On/Off Touch Switch with power indicator
- Auto reset overheat protection
- Dent resistant 1/8" thick rice pot
- Three capacities: 25, 37, and 55 cup
- NSF listed for cook and hold
- Can be used with steamers
- Two Year Limited Warranty

(warranty starts from Town's date of invoice)

Additional features include a stainless steel cover, oil/ water/grease resistant 14 gauge 3 wire electric power cord, rice cup and paddle. The electronic control is water resistant. Separate sensors regulate the cook and hold cycles giving precise temperature control. New style coil relay added for more consistent results.

This is a field tested rice cooker that has brought unsolicited praise from users. It will cook different kinds of rice: long grain, short grain, sushi, brown, Basmati, Texmati, etc. with good results.

Other Uses

The Owner's Manual includes recipes for Rice Pilaf and Jambalaya.

Model	Type	Wt
56822	25 cup, 120 volt	15 lb
56824	25 cup, 230 volt	15 lb
57137	37 cup, 120 volt	21 lb
57138	37 cup, 230 volt	21 lb
57155	55 cup, 230 volt	29 lb
Replacement Rice Pots		
56844	25 cup replacement rice pot	5 lb
57139	37 cup replacement rice pot	6 lb
57155P	55 cup replacement rice pot	9 lb

No.	Watts	Volts	Amps	Hz	cook time*	capacities †		sizes diam‡ x height
						raw rice	cooked rice	
56822	1700	120	14	60	31 min	8 lb (25 cups)	19 lb (50 cups)	14 3/4" x 12"
56824	1500	230	7	50/60	44 min	13 lb (37 cups)	28 lb (74 cups)	15 3/4" x 12 3/4"
57137	2160	120	18	60	43 min	18 lb (55 cups)	42 lb (110 cups)	19" x 15 1/2"
57138	1950	230	9	50/60	48 min			
57155	3330	230	15	50/60	46 min			
no.	liquid cap (qts)	carton size	cut ft	units/carton	ship wt	color ^	cord length	
56822/4	11	35" x 17" x 12"	4.2	2	30 lb			
57137/8	13 1/4	18" x 18" x 13"	2.5	1	21 lb	mustard	72"	
57155	21 1/2	21" x 21" x 16"	3.7	1	31 lb			

* for better rice, allow 10 additional minutes for rice to cure after cooking
† Capacities are approximate
‡ add 3” for handles
^ white is no longer available.

Features:

Durable

Reinforced body, extra-thick heater plate and water resistant controller gives longer unit life.

Fast

Overheat Protection

The high limit control prevents heating element damage or failure due to a dented pot.

Touch Controls & Indicator lights

First touch the ON/OFF button and the unit turns on in the “hold” mode. Both the power and the hold indicator lights will be illuminated. A touch to the PRESS TO COOK button starts the cook cycle. The hold light will go out and the cook light will illuminate. When the rice is cooked the cook light will go out and the hold light will illuminate, indicating the rice is cooked. Unit stays in warm mode until turned off or another cook cycle is started. Touch the power button at any time to turn the unit off.

Automatic Cook and Hold Operation. Touch the Button, Walk Away for Perfect Rice Every Time

An electronic sensor detects when the water has been absorbed to end the cook cycle. Rice-Master® switches to “hold” automatically when cooking is done. Rice will be held at an NSF compliant 150°F+. Holding time should not exceed 5 hours.

1/8” thick Lift Out Rice Pot

Resists dents, removable for washing rice and cleaning.